














DOUBLE SLING GLIDER ASSEMBLY INSTRUCTIONS

PARTS LIST							
A	Swing Brace		2	H	Short Bolt		12
B	Glider Base		1	I	Large Metal Washer		8
C	Left Arm		1	J	Small Metal Washer		8
D	Right Arm		1	K	Plastic Bolt Cap		16
E	Seat / Back		1	L	Allen Wrench		1
F	Cross Bar		2	M	Touch up Paint bottle		1
G	Long Bolt		4				

THEN ENJOY YOUR NEW DOUBLE SLING GLIDER.
 CLEANING USE A MILD DETERGENT AND WARM WATER ON THE FRAMES .
 DO NOT USE ABRASIVE MATERIALS OR CLEANSERS COMMERCIALY
 AVAILABLE.

